

Connection in a RMBT box

Here is the precise procedure to connect cables in a RMBT box:

1. Check the tightness of electricity gloves.
2. Locate the neutral wire: Make a loop with the cable.

FOR EACH CABLE:

3. Mark length.
4. Cut the cable.
5. Mark stripping.
6. Strip.
7. Lubricate according to the type of connector.
8. Insert the cable until it stops.
9. Position the shoe.
10. Tighten up breaking the self-breaking head.
11. Close the cover.
12. Mark the numbers on the cable and repeat the procedure for each cable of the RMBT box.

ONCE THESE STEPS ARE TAKEN, WE MUST MAKE THE EARTHING:

13. After closing the lid, connect the earth to neutral.
14. Connect the earth.
15. After placing the heat shrink, install the ground connector on the loop of the neutral wire.
16. Screw until breaking the self-breaking head.

You have now completed the task.